




# LIGHT

LIG040..

LIG041..





LIG047..

LIG048..




# 1


## Montaggio Assembly




MIN - MAX



OK




2





CALDO  
HOT

FREDDO  
COLD




b




040..  
041..


047..  
048..




# 3




040..  
041..



MAX 35





047..  
048..



MAX 35


047..  
048..

040..  
041..




**4**

**a**




**b**




**5**


**a**




**b**



# M Manutenzione Service




# D Deviatore Diverter







# Sostituzione Cartuccia How to replace Cartridge

040.. 047..  
041.. 048..



# Sostituzione Deviatore How to replace Diverter



# Sostituzione Aeratore How to replace Aerator